

TFPV

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70


Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132


Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Series load cells: **FCAL - FCAX**

Up to 1500 kg application range



TFPV
TFPV2000



TFPVZ

MAX STATIC LOAD	kg	FOR LOAD CELLS	NET WEIGHT (kg)	CODE
500		FCAL - FCAX	2	TFPV
500		FCAL - FCAX	2	TFPVZ
1500		FCAX	2	TFPV2000


Load cell not included.

DESCRIPTION


- Adjustable upper plate in AISI 304 stainless steel (PPV).
- Lower plate and block in AISI 304 stainless steel.
- Constraint against lateral forces and anti-tilt in (TFPV, TFPV2000) AISI 304 stainless steel or (TFPVZ) galvanized steel self-centring joint foot.
- Misalignment compensation of the support plates structure.
- Partial height adjustment.
- Locking screw to avoid damage during transport and installation.

DIMENSIONS AND TECHNICAL SPECIFICATIONS


- During the transport and installation the lock (*) must touch under the load cell. After installation, move the lock away from the load cell.
- Interconnect the plates to the earthing.
- In case of structure with four-point support, if one-point does not touch the upper part of the mounting kit, you must proceed to insert a shim before fixing the bolts.




PIATF




PIATF2000




BLOCT




PPV




PIEDINOSB2ZNC
M12x1.75




PIEDINOSB2INOX
M12x1.75



FIXING TO THE WEIGHED STRUCTURE



POSSIBLE UPPER PLATE POSITIONS



По вопросам продаж и поддержки обращайтесь:		
Алматы (7273)495-231	Казань (843)206-01-48	Новокузнецк (3843)20-46-81
Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73
Астрахань (8512)99-46-04	Калуга (4842)92-23-67	Омск (3812)21-46-40
Барнаул (3852)73-04-60	Кемерово (3842)65-04-62	Орел (4862)44-53-42
Белгород (4722)40-23-64	Киров (8332)68-02-04	Оренбург (3532)37-68-04
Брянск (4832)59-03-52	Краснодар (861)203-40-90	Пенза (8412)22-31-16
Владивосток (423)249-28-31	Красноярск (391)204-63-61	Пермь (342)205-81-47
Волгоград (844)278-03-48	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15
Вологда (8172)26-41-59	Липецк (4742)52-20-81	Рязань (4912)46-61-64
Воронеж (473)204-51-73	Магнитогорск (3519)55-03-13	Самара (846)206-03-16
Екатеринбург (343)384-55-89	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40
Иваново (4932)77-34-06	Мурманск (8152)59-64-93	Саратов (845)249-38-78
Ижевск (3412)26-03-58	Набережные Челны (8552)20-53-41	Севастополь (8692)22-31-93
Иркутск (395)279-98-46	Нижний Новгород (831)429-08-12	Симферополь (3652)67-13-56
Россия (495)268-04-70	Киргизия (996)312-96-26-47	Казахстан (7172)727-132